



**RAM400/1000 corner bass traps can be easily installed with 3M removable hooks as an alternative to using a staple gun. This is ideally suited to brick walls or rental properties. The 1.3 kg 3M Commander hooks work well.**

**Two hooks will support the panel adequately, though four is preferable (two top and two at the bottom). Make a small incision in the staple gun channel and insert the hook. Apply the adhesive tab and then press into the corner. It is advisable to clean the wall with an alcohol swab.**



